



Proper Cleaning Procedures:

Clean units with Sure Klean Custom Masonry Cleaner. Do not deviate from the manufacturer's recommended procedures. Pressure rinse with 500 to 1500 PSI at a water flow rate of 4 to 8 gallons per minute and 15 to 40 degree fan spray. This will ensure an even cleaning after the block and mortars have “set” after a seven to ten days.

Long Term Cleaning Procedures:

Natural rainfall should be more than adequate to keep the concrete masonry units vibrant. Do not deviate from the manufacturer's recommended procedures as stated above if cleaning is absolutely necessary. Pressure Rinse with 500 to 1500 PSI at a water flow rate of 4 to 8 gallons per minute and 15 to 40 degree fan spray only when necessary. Use non-aggressive cleaners as manufacturer recommends. Stains and graffiti should be dealt with immediately.